



SPRENGER SCHLEIFTECHNIK

**SPRENGER FREZE UÇLARI**



**6 mm Sap Çapı**

NO	FORM	KOD	D1	L2	D2	L1	DİŞ
30001	RBF	61606	6	16	6	50	Z3,Z6
30002	RBF	61606	6	16	6	75	Z3,Z6
30003	RBF	82006	8	20	6	65	Z3,Z6
30004	RBF	102006	10	20	6	65	Z3,Z6
30007*	RBF	12,72506	12,7	25	6	70	Z3,Z6
30009	RBF	162506	16	25	6	70	Z3,Z6
30010	RBF	163006	16	30	6	75	Z3,Z6
30021*	RBF	112506	11	25	6	70	Z3,Z6

**6 mm Sap Çapı Alüminyum Diş Tipi**

NO	FORM	KOD	D1	L2	D2	L1	DİŞ
30701	RBF	61606	6	16	6	50	ALU
30702	RBF	102006	10	20	6	65	ALU
30703	RBF	12,72506	12,7	25	6	70	ALU

**6 mm Sap Çapı Uzun Sap**

NO	FORM	KOD	D1	L2	D2	L1	DİŞ
30802	RBF	61303	6	13	6	163	Z3,Z6
30804	RBF	102006	10	20	6	170	Z3,Z6
30806	RBF	12,72506	12,7	25	6	225	Z3,Z6

**3 mm Sap Çapı**

NO	FORM	KOD	D1	L2	D2	L1	DİŞ
30301	RBF	30703	3	7	3	40	Z3,Z6
30302	RBF	30703	3	7	3	50	Z3,Z6
30303	RBF	31303	3	7	3	75	Z3,Z6
30304	RBF	31303	3	13	3	40	Z3,Z6
30305	RBF	31303	3	13	3	50	Z3,Z6
30306	RBF	31303	3	13	3	75	Z3,Z6
30601	RBF	61303	6	13	3	43	Z3,Z6

